

# TAMLYN WINDOW TAPE

WS25 WindowTape is a self-adhering, self-sealing waterproofing tape designed for use around windows, doors, building seams and in general construction. It is composed of a white polymer film that is coated with an aggressive Broad Temperature Spectrum (BTS™) asphalt adhesive. A release liner protects the adhesive and is removed as the tape is installed.

The BTS™ adhesive self-seals around punctures such as nails and staples. This advanced system bonds to all common building and window materials and seals around fasteners to prevent damage caused by water penetration.

## SPECIAL FEATURES

WS25 WindowTape offers the contractor and property owner these extra features:

- Proven and patented, polymer construction resists exposure to ultraviolet rays.
- Aggressive Broad Temperature Spectrum (BTS) adhesive sticks to all common building materials and remains flexible at low temperatures.
- Adheres to prepared substrates of plywood, OSB, masonry, aluminum, vinyl, steel, drywall, insulation board, and house wrap.
- Prevents water, air, insect, and noise infiltration. Helps to prevent mold and mildew.
- Easy-to-remove release liner.
- Uniform thickness for dependable protection.
- Self-seals around fasteners including nails and staples.
- Eliminates Leaks – multiple layers of protection seal out water.
- BTS adhesive won't crack or dry out (when properly installed).
- May be left exposed for 30 days.

## INTENDED USES

Install on the window sill to protect against moisture that can contribute to rot, mold and mildew. Use to seal the window flange to the building wall in new construction to prevent window leaks, seal around doors, under siding, exterior plaster, sill plates and wall joints, or in any application where the membrane is protected from long-term ultraviolet exposure.

### Window Tape (25 mil)

ITEM ID	ROLL SIZE	ROLLS/BX	LIN FT / BX
WS25-4	4" x 75'	9	675
WS25-6	6" x 75'	6	450
WS25-9	9" x 75'	4	300
WS25-12	12" x 75'	3	225

### Window Tape (25 mil)

ITEM ID	ROLL SIZE	ROLLS/BX	LIN FT / BX
WS25-4/100	4" x 100'	9	900
WS25-6/100	6" x 100'	6	600
WS25-9/100	9" x 100'	4	400
WS25-12/100	12" x 100'	3	300




R.H. TAMLYN & SONS, LP  
13623 PIKE ROAD  
STAFFORD TX, 77477

TEL: 281-499-9604, FAX: 281-499-8948

# INSTALLATION PROCEDURE

The installation sequence outlined is very important. All edges must be shingle lapped to prevent entry of water.


## STEP 1 - Sill Flashing



Install horizontal strip on sill

1. Make sure the surface is clean, dust free, smooth, and dry. (Note: Do not apply over silicone caulk or other solvent based products.)
2. Test Window Tape adhesion to sheathing. Some sheathing boards contain components which reduce tape adhesion. Assume that rollers are used for proper bonding.
3. Cut desired length from the roll with utility knife or scissors.
4. Install on wood sill.


## STEP 2 - Set Window



Set window frame

1. Set window per window manufacturer's installation instructions.
2. Use appropriate size and gauge nail per window manufacturer's instructions.


## STEP 3 - Jamb Flashing



Adhere vertical strips to jamb flanges and sheathing


1. Cut desired length from the roll with utility knife or scissors.
2. Adhere Window Tape to window flange and exterior sheathing and/or house wrap.

## STEP 4 - Head Flashing



Adhere horizontal strip to head flange and sheathing.

1. Cut head flashing length 2" extra on each side of rough opening beyond jamb flashing.
2. Adhere Window Tape to head flange and exterior sheathing and/or house wrap.
3. Firmly press or roll the tape to the area being sealed.



For arched window follow above instructions but allow extra length to accommodate radius of window. Use Window Tape 25 mil for sill and jamb flashing.